

Modular Type Regulators Series AR

Regulator Series AR	Model	Port size	Options
	AR10	M5 x 0.8	
	AR20	1/8, 1/4	
	AR25	1/4, 3/8	
Maria	AR30	1/4, 3/8	
	AR40	1/4, 3/8, 1/2	
	AR40-06	3/4	Bracket Square embedded type
	AR50	3/4, 1	pressure gauge (except the AR10)
	AR60	1	Round type pressure gauge
Regulator with Backflow Function Series AR□K	AR20K	1/8, 1/4	Digital pressure switch
	AR25K	1/4, 3/8	(except the AR10) Panel mount
	AR30K	1/4, 3/8	T and mount
Address of the second of the s	AR40K	1/4, 3/8, 1/2	
	AR40K-06	3/4	


AR10 to AR60 Regulator with Backflow Function AR20K to AR60K




• With the backflow function it incorporates a mechanism to exhaust the air pressure in the outlet side reliably and quickly.



Example 2)
When the air supply is cut off and releasing the inlet pressure to the atmosphere, the residual pressure release of the outlet side can be ensured for a safety purpose.



How to Order



- Option/Semi-standard: Select one each for a to g.
- Option/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order.
 Example) AR30K-03BE-1NR

(Refer to pages 354 and 355 for details.) 0 Symbol Description Body size 10 20 25 30 40 50 60 With backflow Nil Without backflow function 2 K Note 1 function With backflow function + Metric thread (M5) Nil Rc 8 Thread type Ν **NPT** • • F • G + **M5** M5 01 1/8 • 02 1/4 • • • 4 03 3/8 • • • Port size 04 • 1/2 06 • • 3/4 10 • 1 + Nil • Without mounting option B Note 3) • а Mounting With bracket Н With set nut (for panel fitting) + Nil Without pressure gauge Ε Square embedded type pressure gauge (with limit indicator) Option Pressure Round type pressure gauge (without limit indicator) G gauge Round type pressure gauge (with limit indicator) b Round type pressure gauge (with color zone) **E1** Note 4) Output: NPN output / Electrical entry: Wiring bottom entry Digital **E2** Note 4) Output: NPN output / Electrical entry: Wiring top entry pressure E3 Note 4) Output: PNP output / Electrical entry: Wiring bottom entry switch Output: PNP output / Electrical entry: Wiring top entry





AR20, AR20K

AR40, AR40K

									0					
	Symbol				Description	Body size								
						10)	20	25	30	40	50	60	
			Cot proceuro	Nil Note 5)	0.05 to 0.85 MPa setting)	•	•	•	•	•	•	
		С	Set pressure	1 Note 6)	0.02 to 0.2 MPa setting)	•	•	•	•	•	•	
				+										
		d	Exhaust	Nil	Relieving type)		•	•		•		
		u	mechanism	N	Non-relieving type)		•	•		•		
	ard			+										
	Semi-standard	е	Flow direction	Nil	Flow direction: Left to right)	•	•	•	•	•		
6	sta	-	riow direction	R	Flow direction: Right to left)	•	•	•		•		
	Ë			+										
	Se	f	Knob	Nil	Downward)	•	•	•		•		
		•	KIIOD	Υ	Upward)	•	•	•	•	•	•	
				+										
				Nil	Name plate and pressure gauge in imperial units: MPa			•	•	•	•	•	•	
		g	g	Pressure unit	Z Note 7)	Name plate and pressure gauge in imperial units: psi	ON	ote 9)	Note 9)	Note 9)	Note 9)	Note 9)	Note 9)	Note 9)
				ZA Note 8)	Digital pressure switch: With unit conversion function		-	∑Note 10)	△Note 10)					

- Note 1) The AR10 type comes with a backflow function as a standard feature. (K is not available.) When using the AR10 type as w/ backflow function, backflow may not occur with the set pressure 0.15 MPa or less. Please set the inlet pressure to at least 0.05 MPa higher than the set pressure.
- Note 2) Option B, G, H, M are not assembled and supplied loose at the time of shipment.
- Note 3) Assembly of a bracket and set nuts (AR10, AR20(K) to AR40(K)) Including 2 mounting screws for the AR50(K) and AR60(K)
- Note 4) When choosing with H (panel mount), the installation space for lead wires will not be secured. In this case, select "wiring top entry" for the electrical entry. (Select "wiring bottom entry" when the semi-standard Y is chosen simultane-
- ously.)
 Note 5) Only the AR10 has a pressure setting of 0.05 to 0.7 MPa.

- Note 6) The only difference from the standard specifications is the adjusting spring for the regulator. It does not restrict the setting of 0.2 MPa or more. When the
- pressure gauge is attached, a 0.2 MPa pressure gauge will be fitted.

 Note 7) For thread type: M5 and NPT. This product is for overseas use only according to the new Measurement Law. (The SI unit type is provided for use in Japan.) The digital pressure switch will be equipped with the unit conversion function,
- setting to psi initially.

 Note 8) For options: E1, E2, E3, E4. This product is for overseas use only according to the new Measurement Law. (The SI unit is provided for use in Japan.) Note 9) \bigcirc : For thread type: M5 and NPT only
- Note 10) △: Select with options: E1, E2, E3, E4.

Standard Specifications

Standard Specifications	5											
Model	AR10	AR20(K)	AR25(K)	AR30(K)	AR40(K)	AR40(K)-06	AR50(K)	AR60(K)				
Port size	M5 x 0.8	1/8, 1/4	1/4, 3/8	1/4, 3/8	1/4, 3/8, 1/2	3/4	3/4, 1	1				
Pressure gauge port size Note 1)	1/16 Note 2) 1/8 1/4											
Fluid		Air										
Ambient and fluid temperature Note 3)		−5 to 60°C (with no freezing)										
Proof pressure				1.5	MPa							
Maximum operating pressure				1.0	MPa							
Set pressure range	0.05 to 0.7 MPa			0.05 to 0).85 MPa							
Relief pressure Note 4)		Se	t pressure + 0	.05 MPa [at re	lief flow rate o	f 0.1 ℓ/min (AN	R)]					
Construction				Relievi	ng type							
Mass (kg)	0.06	0.26	0.21	0.29	0.44	0.47	1.17	1.22				

Note 1) Pressure gauge connection threads are not available for F.R.L. unit with a square embedded type pressure gauge (AR20(K) to AR60(K)).

Note 2) Use a bushing (part no:131368) when connecting the R1/8 pressure gauge to the Rc1/16.

Note 3) -5 to 50°C for the products with the digital pressure switch.

Note 4) Not applicable to the AR10.

Series AR10 to AR60 Series AR20K to AR60K

Options/Part No.

Option			AR10	AR20(K)	AR25(K)	AR30(K)	AR40(K)	AR40(K)-06	AR50(K)	AR60(K)			
Bracket assembly Note 1)			AR10P-270AS	AR20P-270AS AR25P-270AS AR30P-270AS			AR40P	-270AS	AR50P-270AS Note 2)				
Set nut			AR10P-260S	AR20P-260S	AR25P-260S	AR30P-260S	AR40F	2-260S	Note 3)	Note 3)			
	Note 4) Round	Standard	G27-10-R1		G36-10-□01			G46-1	0-□02				
Press-	type	0.02 to 0.2 MPa setting	G27-10-R1 ^{Note 5)}		G36-2-□01		G46-2-□02						
	Note 4) Round	Standard	_		G36-10-□01-L	-	G46-10-□02-L						
gauge	type (with color zone)	0.02 to 0.2 MPa setting	_		G36-2-□01-L		G46-2-□02-L						
	Square Note 6)	Standard	_	GC3-10AS [GC3P-010AS (Pressure gauge cover only)]									
	ambaddad	0.02 to 0.2 MPa setting	_	GC3-2AS [GC3P-010AS (Pressure gauge cover only)]									
		NPN output: Wiring bottom entry			ISE35-1	N-25-MLA [ISE	35-N-25-M (S	witch body onl	y)] Note 7)				
Digita		NPN output: Wiring top entry			ISE35-I	R-25-MLA [ISE	E35-R-25-M (Switch body only)] Note 7)						
pressi		PNP output: Wiring bottom entry	_		ISE35-1	N-65-MLA [ISE	35-N-65-M (S	witch body onl	y)] Note 7)				
		PNP output: Wiring top entry			ISE35-R-65-MLA [ISE35-R-65-M (Switch body only)] Note 7)								

Note 1) Assembly of a bracket and set nuts

Note 2) Assembly of a bracket and 2 mounting screws

Note 3) Please consult with SMC regarding the set nuts for the AR50(K) and AR60(K).

Note 4) \square in part numbers for a round pressure gauge indicates a type of connection thread. No indication is necessary for R; however, indicate N for NPT. Please contact SMC regarding the connection thread NPT and pressure gauge supply for psi unit specifications.

Note 5) Pressure gauge for general purpose

Note 6) Including one O-ring and 2 mounting screws. []: Pressure gauge cover only

Note 7) Lead wire with connector (2 m), adapter, lock pin, O-ring (1 pc.), mounting screw (2 pcs.) are attached. []: Switch body only Also, regarding how to order the digital pressure switch, please refer to page 388.

⚠ Specific Product Precautions

Be sure to read before handling. Refer to front matters 42 and 43 for Safety Instructions and pages 287 to 291 for F.R.L. I Precautions.

Selection

⚠ Warning

 Residual pressure disposal (outlet pressure removal) is not possible for the AR20 to AR60 even though the inlet pressure is exhausted. When the residual pressure disposal is performed, use the regulator with a backflow function (AR20K to AR60K).

Maintenance

Marning

 When using the regulator with backflow function between a solenoid valve and an actuator, check the pressure gauge periodically. Sudden pressure fluctuations may shorten the durability of the pressure gauge. A digital pressure gauge is recommended for such situation or as deemed necessary.

Mounting and Adjustment

⚠ Warning

- Set the regulator while verifying the displayed values of the inlet and outlet pressure gauges. Turning the regulator knob excessively can cause damage to the internal parts.
- 2. The pressure gauge included with regulators for 0.02 to 0.2 MPa setting is for up to 0.2 MPa use only (except the AR10). Exceeding 0.2 MPa of pressure can damage the gauge.
- **3.** Do not use tools on the pressure regulator knob as this may cause damage. It must be operated manually.

∧ Caution


- Be sure to unlock the knob before adjusting the pressure and lock it after setting the pressure. Failure to follow this procedure can cause damage to the knob and the outlet pressure may fluctuate.
- Pull the pressure regulator knob to unlock. (You can visually verify this with the "orange mark" that appears in the gap.)
- Push the pressure regulator knob to lock. When the knob is not easily locked, turn it left and right a little and then push it (when the knob is locked, the "orange mark", i.e., the gap will disappear).





A knob cover is available to prevent careless operation of the knob. Refer to page 389 for details.


Flow Characteristics (Representative values)


Condition: Inlet pressure 0.7 MPa























Series AR10 to AR60 Series AR20K to AR60K


Pressure Characteristics (Representative values)


Conditions: Inlet pressure 0.7 MPa, Outlet pressure 0.2 MPa, Flow rate 20 \(\ell \)min (ANR)






















Construction


AR10




AR30(K), AR40(K)




AR20(K), AR25(K)




AR50(K), AR60(K)



AR20K to AR60K (Regulator with Backflow Function)





Component Parts


No.	Description	Material	Model	Color		
4	Pody	Zinc die-cast AR10, AR20(K)				
•	Body	Aluminum die-cast	AR25(K) to AR60(K)	Platinum silver		
_	Bonnet	Polyacetal	AR10, AR20(K) to AR40(K)-06	- Black		
2	Bonnet	Aluminum die-cast	AR50(K), AR60(K)			

Replacement Parts

nep	iacement Farts												
No.	Description	Material	Part no.										
INO.			AR10	AR20(K)	AR25(K)	AR30(K)	AR40(K)	AR40(K)-06	AR50(K)	AR60(K)			
3	Valve assembly	Brass, HNBR	AR10P-090S	AR20P-410S	AR25P-410S	AR30P-410S	AR40I	AR40P-410S		AR60P-410S			
4	Diaphragm assembly	Weatherable NBR	AR10P-150AS Note 1)	AR20P-150AS	AR25P-150AS	AR30P-150AS	AR40P-150AS		AR50P-150AS				
5	Valve guide assembly	Polyacetal	131329	AR20P-050AS	AR25P-050AS	AR30P-050AS	AR40P-050AS		AR50P-050AS	AR60P-050AS			
6	Check valve assembly Note 2)	_	_	— AR20KP-020AS									

Series AR10 to AR60 Series AR20K to AR60K

Working Principle (Regulator with Backflow Function)




When the inlet pressure is higher than the regulating pressure, the check valve operates as a normal regulator (Figure 1).

When the inlet pressure is shut off and exhausted, any inlet pressure applied to the valve ① will be lost. The force for seating the valve ① is the valve spring force ② only. When the valve ① is opened using the outlet force, the outlet pressure will be exhausted at the inlet side. (Figure 2)

When the set pressure is 0.15 MPa or less, valve ① may not open due to the valve spring ② force.


AR20K to AR60K



When the inlet pressure is higher than the regulating pressure, the check valve ② closes and operates as a normal regulator (Figure 1). When the inlet pressure is shut off and released, the check valve ② opens and the pressure in the diaphragm chamber ① is released into the inlet side (Figure 2).

This lowers the pressure in the diaphragm chamber ① and the force generated by the pressure regulator spring ③ lifts the diaphragm. Valve ④ opens through the stem, and the outlet pressure is released to the inlet side (Figure 2).

Dimensions



				04		"4"						Ор	tional sp	ecification	ns			
Model		Standard specifications									Square type pressure gauge		Digital pressure switch		Round type pressure gauge		Round type pressure gauge (with color zone)	
	P1	P2	Α	B Note 1)	С	D	F	J	K	Н	J	Н	J	Н	J	Н	J	
AR10	M5 x 0.8	1/16	25	58	11	12.5	M18 x 1	13	0	_	_	_	_	ø26	26	_	_	
AR20(K)	1/8, 1/4	1/8	40	94	26.5	28.5	M28 x 1	28.5	2 ^{Note 2)}	□28	29.5	□27.8	40	ø37.5	65	ø37.5	65	
AR25(K)	1/4, 3/8	1/8	53	101	28	27.5	M32 x 1.5	27.5	0	□28	28.5	□27.8	39	ø37.5	64	ø37.5	64	
AR30(K)	1/4, 3/8	1/8	53	116	31	29.5	M38 x 1.5	29.5	3.5	□28	30.5	□27.8	41	ø37.5	66	ø37.5	66	
AR40(K)	1/4, 3/8, 1/2	1/4	70	128	36	34	M42 x 1.5	34	3.5	□28	35	□27.8	45	ø42.5	74	ø42.5	74	
AR40(K)-06	3/4	1/4	75	129	36	34	M42 x 1.5	34	3	□28	35	□27.8	45	ø42.5	74	ø42.5	74	
AR50(K)	3/4, 1	1/4	90	169	43	43.5	M62 x 1.5	43.5	3.3	□28	44.5	□27.8	55	ø42.5	84	ø42.5	84	
AR60(K)	1	1/4	95	176	46	43.5	M62 x 1.5	43.5	3.3	□28	44.5	□27.8	55	ø42.5	84	ø42.5	84	

	Optional specifications										
Model			Br	Panel mount							
	М	N	Q	R	S	Т	U	V	W	Υ	Z
AR10	25	28	30	4.5	6.5	40	2	18	18.5	_	_
AR20(K)	30	34	44	5.4	15.4	55	2.3	25	28.5	14	6
AR25(K)	30	34	44	5.4	15.4	55	2.3	26	32.5	16	6
AR30(K)	41	40	46	6.5	8	53	2.3	31	38.5	19	7
AR40(K)	50	54	54	8.5	10.5	70	2.3	35.5	42.5	21	7
AR40(K)-06	50	54	56	8.5	10.5	70	2.3	37	42.5	21	7
AR50(K)	70	66	65.8	11	13	90	3.2	_	_	_	_
AR60(K)	70	66	65.8	11	13	90	3.2	_	_	_	_

Note 1) The total length of B dimension is the length when the filter regulator knob is unlocked. Note 2) For the AR20 only, the position of the pressure gauge is above the center of the piping.